











# MULTI-TOUCH PANEL

## USER GUIDE

### Basic control




### Multi-Touch gestures


<b>Click and select object</b>	Briefly touch surface with fingertip	 tap
<b>Open</b>	Rapidly touch surface twice with fingertip	 double tap
<b>Right click</b>	Touch surface for <b>2 seconds</b>	 press   Hold for 2 seconds
<b>Move object</b>	Move fingertip over the object without losing contact	<b>Drag</b> 
<b>Zoom in and out</b>	Touch surface with two fingers and bring them closer together or move them apart	 pinch
<b>Rotate</b>	Touch surface with two fingers and move them in a clockwise or counterclockwise direction	<b>Rotate</b>  OR 

## How to use


1. Please enter your login ID and password for single sign-on



2. Do not cancel the printer installation



3. To open the On-Screen Keyboard (in the bottom right corner)




## How to connect your notebook computer




HDMI, VGA and AUDIO are provided to connect your notebook computer

1. Open the cabinet
2. Choose an appropriate connection port  
\*If you would control your notebook computer via the touch panel, please use the USB port (in red circle)
3. Select the input source (HDMI-1 or VGA)

Some applications are installed to facilitate group discussion, presentation and study. The manuals in appendixes highlight some major functions.



eMarker is an application for computers and mobile devices to facilitate interactive presentation and discussion.



Multi-Touch provides comprehensive drawing tools for discussion and brainstorming.



Mirroring360 allows users to share the screen of your personal devices to a target computer without any hardware or cable.-Play Store"; Mirroring360 Sender from Chrome.